

## Inspection Frequency Guide

Inspection intervals as described by the applicable Australian Standards and manufacturers instructions

Equipment Category	Interval	Standard
'C'Hook	12 Monthly	AS 4991
Chain Block	12 Monthly	AS 1718.2
Chain Slings	12 Monthly	AS 3775.2
Concrete Lifting Clutches *	12 Monthly	AS 3850.1
Crane Cage & Boxes	12 Monthly	AS 1418.17
Eye Bolts	12 Monthly	AS 2317
Eye Nuts	12 Monthly	AS 2317
Fabricated Lifting Devices	12 Monthly	AS 4991
Fall Arrest /Inertia Reels *	6 Monthly	AS 1891.4
Forklift Jibs & Attachments	12 Monthly	AS 2359.1
Forklift Work Boxes	12 Monthly	AS 2359.1
Girder Clamps	12 Monthly	AS 4991
Harness & Height Safety	6 Monthly	AS 1891.4
Lever Hoists	12 Monthly	AS 1718.2
Plate Clamps	12 Monthly	AS 4991
Portable Ladders	6 Monthly	AS 1892.5
Shackles	12 Monthly	AS 2741
Spreader Bars & Beams	12 Monthly	AS 4991
Synthetic Round Slings	12 Monthly	AS 4991
Synthetic Web Slings	3 Monthly	AS 1353.2
Wire Rope Slings	3 Monthly	AS 1666.2

\*These equipment types must be serviced/tested annually

**If you require an equipment inspection, please give us a call: 3801 6565**



Regular Inspections are essential to ensure you are maintaining your Lifting & Height Safety Equipment to the relevant Australian Standards.

Please use our QR Code to take you to our Pre-start Inspection checklists to ensure your equipment is fit for use before starting work.

**EAGLE FARM – MARYBOROUGH – WACOL - YATALA**