

Fall Arrest Block Inspection

How to inspect before use

Ensure your safety, the safety of your site and teammates when conducting inspections. All inspections of Fall Arrest Blocks shall be conducted in accordance with the relevant standards.

Inspect all the components of the Fall Arrest Block thoroughly


1. Manufacturer Tag/Label



2. Body/Outer Case and Mechanism/s



3. Webbing or Rope



4. Fittings/Attachments & Fall Indicators



what to look for

Bent, Corroded, Cracked, Cut, Deformed, Distorted, Gouged, Heat Damage, Jammed, Nicked, Seized, Unreadable, Worn.

NOTE: Pay particular attention to the load indicator for signs of deployment.

If any doubt is raised regarding the Fall Arrest Block NOT being fit for service, tag accordingly and contact us on 3801 6565.

HEAD OFFICE

A. 4 Christensen Rd, Yatala Q 4207

T. 07 3801 6565

W. stenhouسلifting.com.au

EAGLE FARM 07 3473 2453

MARYBOROUGH 07 4122 1193

WACOL 07 3728 4545

